SERVICE PARTS LIST SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS M18™ FORCELOGIC™ 3" Underground Cable Cutter CAT. NO. 2776-20 (Non-Remote) SERIAL NUMBER H49A & B CAT. NO. 2776R-20 (Wireless Remote) SERIAL NUMBER H50A & B &	BULLETIN NO. 54-00-2776 SED BULLETIN DATE Apr. 2025			
CUTTER HEAD SERVICE PARTS PAGE 2 LUBRICATION INSTRUCTIONS	PAGE 3			
ACCESSORIES PAGE 2 TORQUE SPECIFICATIONS	PAGE 4			
Due to the combination of hydraulics and electronics in thi	s tool,			
service can only be performed at Milwaukee Authorized Hydraulic Repair Centers:				
MILWAUKEE TOOL Central Repair				
1401 Sycamore Avenue ● Greenwood, MS 38930-72	77			
Please send your tool directly to this location for service	э.			
Or				
Via e-Service at: www.milwaukeetool.com/e-service	e			
questions, please call 1.800.SAWDUST (1.800.729.387	8)			
Or				
Visit www.milwaukeetool.com to find your closest				
Milwaukee authorized Hydraulic repair center				
Or				
Return it to a MILWAUKEE <i>factory</i> Service Center location, freight prep				

A copy of the proof of purchase should be included with the return product.


If you have questions please contact Milwaukee Product Service at: **Product Technical Support via phone at: 262.783.8642**

Or

Via email at: METProductSupport @milwaukeetool.com

Disassembly is not recommended and could void the warranty.

Accessories and External Service Parts for 2776-20 & 2776R-20 3" Underground Cable Cutters



NOTE:

If the tool you are servicing has the old version of the M18 screw bolt (1f), you must also order screw bolt kit 42-32-0265 (79) when ordering the grounding service kit 14-46-0452 (83).


FIG . 1	PART NO.	DESCRIPTION OF PART I Underground Cutter Head Assembly	NO. REQ. (1)
1a		M5 x 18mm Cap Screw 4mm Hex Dr	ive (2)
1b		Spring Washer	(2)
1c		Blade Retainer	(1)
1d		Left Blade	(1)
1e		M17 Nut	(2)
1f		M18 Screw Bolt	(1)
1g		Washer	(3)
1h		Right Blade	(1)
1j	44-60-0049	Pin	(4)
1k	44-66-0116	Connector Plate	(4)
1m	44-14-0075	T-Connector	(1)
1n	34-80-1300	Retaining Ring	(4)
1p		Clevis - Underground Cutter	(1)
1q		Stop Ring	(1)
1r		Bail Handle Grip	(1)
1s		M6 x 22mm Pan Hd. Phillips Screw	(2)
1t		Bail Handle Support - Left	(1)

NOTE:

The original design of this tool utilized two jam nuts (1e) to aid in securing the Cutting Blades (82) in the Clevis Assembly (81). One M17 Nylok® Hex Nut now replaces the two jam nuts. When servicing the tool, DO NOT attempt to reuse the two jam nuts ... remove and discard.

FIG.	PART NO.	DESCRIPTION OF PART NO. REQ
1u		Bail Handle Support - Right (1)
1v		M8 x 6.5 Screw with 8mm Hex Drive (2)
1w		Extended Point Set Screw (1)
1x		Thread Adapter (1)
1y		Grounding Ball Stud (1)
1z		Rubber Plug (1)
78	14-34-0122	Bail Handle Kit (1)
79	42-32-0265	Screw Bolt Kit (Accessory) (1)
80	44-60-0059	Pin Kit (1)
81		Clevis Assembly (1)
82	49-16-2774	Replacement UG Cutter Blade Set (1)
83	14-46-0452	Grounding Service Kit (Accessory) (1)
84	10-20-1119	Label for Wireless Remote (Not Shown)(1)
85	42-70-0027	Carabiner (Not Shown) (1)
86	48-22-8280	Underground Cutter Bag (Not Shown) (1)
87	22-80-2776	Remote Control
		For 2776R-20 Only (Not Shown) (1)

LUBRICATION INSTRUCTIONS




NOTE

Regarding parts to receive thread locking sealant: Place one to two drops of the recommended Loctite thread locking sealent (or the equivelant) to the threads of parts shown prior to installation.

NOTE

Regarding parts to be lubricated:


Apply a light coating of grease to all highlighted parts shown prior to installation. Reference the key above for grease types.



NOTE:

The original design of this tool utilized two jam nuts (1e) to aid in securing the Cutting Blades (82) in the Clevis Assembly (81). One M17 Nylok[®] Hex Nut now replaces the two jam nuts. When servicing the tool, DO NOT attempt to reuse the two jam nuts...remove and discard.

TORQUE SPECIFICATIONS



NOTE:

The original design of this tool utilized two jam nuts (1e) to aid in securing the Cutting Blades (82) in the Clevis Assembly (81). One M17 Nylok[®] Hex Nut now replaces the two jam nuts. When servicing the tool, DO NOT attempt to reuse the two jam nuts...remove and discard.

	Cutter Head Assembly									
Torque Specifications *Red denotes Critical Torque										
Fig.	Part No.	Part or Where Used			lb-in					
1a		M5 x 18 Screw (Blade Retainer)	100	±3	86.8	±2				
1e		M17 Hex Nut	175	±3	151.9	±2				
1s		M6 x 22 Screw (Bail Handle Support)	30	±3	26.04	±2				
1v		M12 x 6.5 Screw (Bail Handle Support)	100	±3	86.8	±2				
1w		Extended Point Set Screw (Clevis)	10	±1	8.6	±1				