WIRING INSTRUCTIONS

TITLE


WORM DRIVE SAWS

MILWAUKEE ELECTRIC TOOL CORP.

13135 WEST LISBON RD. BROOKFIELD, WIS

Date July '69

BULLETIN 58-01-0340



USE LOCK WASHERS UNDER ALL SWITCH TERMINALS.

WHERE TERMINAL AND CONNECTOR COMBINATIONS ARE SPECIFIED, SEE ELECTRICAL PARTS CHART FOR PART NO. AND QUANTITY AND DRAWING FOR ACTUAL HOOK-UP

WIRING SPECIFICATIONS																					
Wire	Wire		Lgth.	Terminal				Connector			or I	Wire	Wire	Ga.	Lgth.	Terminal			Connector		
Color	No.	Ga.	in.	T1	T2	T3	T4	C1	C2	C3	C4	Color	No.	Ga.	in.	T 1	T2	Т3	T4	CIC	2 C3
Yellow	1	Fld.	2-1/2						 												
Yellow	2	16	8-3/4	x							-										
Black	3	Fld.	8	x																	
White	4	Cord	2-3/8	х					ļ						:						
Black	5	Cord	2-3/8	х																	
Green	6	Cord	2-3/8		Х				i		ĺ										

NOTE: ALL LEADS MUST BE HELD TO ± 1/8" ALL FIELD LEADS TO BE MEASURED FROM AND PERPENDICULAR TO LAMINATIONS. ALL LEAD LENGTHS ARE BEFORE STRIPPING.

Electrical Parts									
TERMINAL DESCRIPTION									
Code	Part No.	Qnty.							
TI	23-74-0330	4							
Т2	23-74-0050	1							
CONNECTOR DESCRIPTION									
Code	Part No.	Qnty.							
SWITCH DESCRIPTION									
Code	Part No.	Qnty.							
s1	23-66-0500	1							

Form OE-24