



SERVICE PARTS LIST

7000 WATT ALTERNATOR

Catalog No. **4790**

Starting
Serial No. **439-1001**

Both Model and Serial No. must be furnished to obtain correct parts.

BUL.54-00-0930


REVISED BUL

DATE
June '70

WIRING INSTR.

54-00-0950

For Engine Replacement Parts or Service, Refer to Manufacturers Name Plate and Contact their Nearest Service Center.




ENGINE ACCESORIES

NOTE: TO ORDER AN EXACT REPLACEMENT ENGINE SPECIFY METCO NO 43-20-4500

Item	Part No.	Req'd	Description
1	44-66-5270	1	Choke Mounting Plate Assembly
2	06-57-7500	2	1 1/4 N.P.T. Pipe Locknut
3	43-33-0400	1	1 1/4 N.P.T. x 1/2 Lg. Nipple
4	43-33-0420	1	1 1/4 N.P.T. x 45° Elbow
5	43-33-0410	1	1 1/4 N.P.T. x 1 3/4 Lg. T.O.E. Nipple
6	42-68-0260	3	Muffler Clamp Assembly
7	43-31-0250	1	Muffler (Stainless Steel)
9	44-66-5280	1	Muffler Support Plate
10	06-75-0343	2	5/16-18 x 2 1/2 Lg. Stressproof Capscrew
11	06-97-4100	5	5/16 Lockwasher - Split
12	06-55-1980	3	5/16-18 Hex. Nut
13	45-88-5245	3	5/16 Flat Washer
14	45-56-0120	1	Adjusting Strap
15	06-75-0340	3	5/16-18 x 1" Lg. Hex. Hd. Capscrew
16	06-75-0500	2	3/8-16 x 1" Lg. Hex. Hd. Capscrew
17	40-50-6900	1	Spring
18	43-54-0230	1	Muffler Guard
19	06-92-2510	1	Air Cleaner Stud
20	45060-0280	1	Air Cleaner Support
21	06-57-5005	1	1/4-28 Locknut
22	42-36-0690	1	Lifting Eye
23	06-85-1740	4	10 Sheet Metal Screw
24	06-75-0100	2	1/4-20 x 3/4 Lg. Hex. Hd. Capscrew
25	06-97-1000	2	1/4 Lockwasher
26	06-55-1500	2	1/4-20 Hex Nut
27	44-94-0180	1	Choke Control Rod
28	06-81-8650	1	6-32 x 1/4 Lg. Sems Sc. & L.W.
29	43-44-0310	1	Automatic Choke & Gasket
30	42-68-0270	1	Choke Lever Clamp
31	45-88-5261	1	3/8 Flat Washer
32	06-97-4125	2	3/8 Lockwasher
33	06-55-2400	2	3/8-16 Hex Nut

LOW OIL SHUT-OFF SYSTEM



Item	Part No.	Req'd	Description
1	23-66-0850	1	Low Oil Shut-off Switch Assembly
2	45-66-0060	1	Oil Tank
3	43-64-0101	1	Pump Head Assembly
4	43-33-0320	1	Probe Assembly
5	45-76-0170	1	Rubber Hose
6	42-68-0280	1	Hose Clamp
7	43-33-0330	1	90° Tank Outlet
8	45-56-0130	2	Oil Tank Strap
9	06-75-0150	4	1/4-20 x 1" Lg. Hex. Hd. Capscrew
10	06-97-1000	4	1/4 Lockwasher - Split
11	06-55-1500	4	1/4-20 Hex Nut
12	45-60-0290	1	Oil Tank Support Assembly
13	06-75-0340	2	5/16-18 x 1" Lg. Hex. Hd. Capscrew
14	06-97-4100	2	5/16 Lockwasher - Split
15	06-55-1980	2	5/16-18 Hex Nut
16	42-52-0210	1	Filler Cap