



SERVICE PARTS LIST

BUL.54-40-2001

WORM DRIVE SAW

REVISED BUL
6368-2DATE
April '68**Catalog No.****6370**Starting
Serial No. **368-3701**

WIRING INSTR.

Both Model and Serial No. must be furnished to obtain correct parts

ILLUSTRATED PARTS

FIG.	PART NO.	DESCRIPTION OF PART	NO.REQ.	FIG.	PART NO.	DESCRIPTION OF PART	NO.REQ.
1	34-60-0525	Pivot Pin Retaining Ring	(2)	40	06-81-5800	6-32x5/16 Fil.Hd. Sem Guard Handle Scr.	(2)
2	44-60-0341	Pivot Pin		41	45-06-0130	Oil Seal	
3	06-81-3700	8-32x7/8 Oval Hd. Guard Cover Scr.	(3)	42	06-81-2675	10-24x1 Flat Hd. Soc. Drive Scr.	(2)
4	06-57-5050	5/16-24 Lock Nut		43	06-81-2665	10-24x5/8 Flat Hd. Soc. Drive Scr.	(2)
5	45-88-0610	Lock Nut Washer		44	14-32-0130	Guard Assembly	
6	28-72-1061	Bearing Cover Plate		45	42-38-0100	Guard Bumper	
7	43-44-0240	Bearing Cover Plate Gasket		46	45-88-0570	Bumper Washer	
8	06-81-6200	8-32x5/8 Fil.Hd. Sem Bearing Cover Plate Scr. (4)		47	06-81-5500	8-32x3/8 Binder Hd. Guard Bumper Scr.	
9	02-04-0975	Ball Bearing		48	14-74-0160	Shoe Assembly	
10	32-91-0101	Worm		49	28-20-2521	Guard Cover	
11	45-36-0481	Worm Spacer		50	45-88-5245	Lock Nut Washer	(2)
12	34-40-1600	'O' Ring		51	06-10-1000	5/16-18x3/4 Carriage Bolt	
13	28-90-0141	Bearing Support		52	06-81-6075	10-24 x 5/8 Flat Hd. Soc. Drive Scr.	
14	06-81-8060	8-32x1/2 Oval.Hd. Sem Bearing Support Scr. (4)		53	40-50-7200	Guard Spring	
15	02-04-1535	Ball Bearing		54	44-40-0250	Spring Anchor Nut	
16	34-80-2400	Bearing Retaining Ring		55	06-81-6075	8-32 x 3/8 Fil. Hd. Sem Spring Anchor Scr.	
17	42-14-0120	Baffle		56	30-89-0401	Guard Support	
18	34-80-4500	Retaining Ring		57	34-60-2150	Guard Retaining Ring	
19	18-82-1200	Field Assembly		58	43-34-0131	Blade Inner Flange	
20	06-81-9225	10-24 x 2-3/4 Rd. Hd. Sem Field Scr. (2)		59	45-04-0340	Blade Retaining Scr.	
21	28-50-6051	Motor Housing		60	43-34-0141	Blade Outer Flange	
22	16-82-1800	Armature Assembly		61		Saw Blades (See Catalog)	
23	02-04-1070	Ball Bearing		62	02-04-1745	Ball Bearing	
24	45-88-0580	Wave Washer		63	34-40-2000	'O' Ring	
25	23-66-0500	Trigger Switch		64	28-90-0121	Spindle Bearing Support	
★26	28-44-9282	Switch Handle Half		65	45-06-0140	Oil Seal	
27	44-76-0050	Cord Protector		66	45-36-0471	Spindle Spacer	
28	06-81-7025	10-24x3/4 Fil. Hd. Sem Handle Scr. (4)		67	32-90-0101	Worm Gear	
29	22-64-0430	Cord Set		68	06-42-2200	#6 Woodruff Key	
30	22-22-0240	Brush Holder Assembly	(2)	69	02-04-1255	Ball Bearing	
31	22-18-0095	Carbon Brush Assembly	(2)	70	45-88-0590	Wave Washer	
32	23-44-0050	Brush Retaining Screw	(2)	71	28-14-1241	Gear Case	
33	44-10-0090	Shoe Clamping Lever	(2)	72	38-50-4851	Spindle	
34	42-42-0091	Plug Button		73	44-68-0130	Oil Plug	
35	44-20-0070	Lever Lock	(2)	74	43-44-0230	Oil Plug Gasket	
36	06-81-5400	8-32x5/16 Binder Hd. Lever Lock Scr. (2)		75	06-81-6200	8-32x5/8 Fil. Hd. Sem Top Handle Scr. (2)	
37	44-40-0240	Shoe Adjustment Nut	(2)	76	06-75-3100	1/4-20 x 1 Soc. Hd. Gear Case Cap Scr. (3)	
38	06-92-0750	5/16-18 x 1-1/8 Body Stud		77	06-97-3800	Gear Case Lock Washer	(4)
39	43-62-0390	Guard Handle		78	28-44-1181	Top Handle	
				★79	28-20-3592	Switch Handle Cover	

MISCELLANEOUS PARTS NOT SHOWN

PART NO.	DESCRIPTION OF PART	NO.REQ.	PART NO.	DESCRIPTION OF PART
06-81-3640	8-32 x 5/8 Oval Hd. Switch Cover Scr.	(4)	06-87-2600	Rip Fence Thumb Scr.
06-81-5500	8-32 x 3/8 Binder Hd. Sem Switch Mtg. Scr.		12-98-6800	Name Plate
06-81-8400	4-40 x 1/4 Round Hd. Sem Name Plate Scr.	(2)	40-50-1300	Rip Fence Thumb Scr. Spring
06-81-8625	6-32 x 1/4 Round Hd. Sem Ground Scr.		★49-02-0070	Rip Fence
06-83-2650	1/4-20 x 3/8 Brush Holder Set Scr.	(2)	06-75-0150	1/4-20 x 1 Hex. Hd. Gear Case Cap Screw
49-96-6300	Saw Wrench		49-32-0050	1/2 Pint Oil
48-03-0010	Attachment Plug Adaptor			

