

## **SERVICE PARTS LIST**


**BULLETIN NO.  
54-42-5852**

<b>SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS</b>		<b>REVISED BULLETIN</b>	<b>DATE</b>
<b>SCREW-SHOOTER MAGAZINE ATTACHMENT</b>		54-42-5851	Apr. 2002
<b>WIRING INSTRUCTION</b>			
<b>CATALOG NO.</b> <b>48-05-1000</b>	<b>STARTING SERIAL NO.</b>	<b>119408022</b>	

## **EXAMPLE:**

**00** Component Parts (Small #) Are Included  
0 When Ordering The Assembly (Large #).

★=Part number change from previous service parts list.



<b>FIG.</b>	<b>PART NO.</b>	<b>DESCRIPTION OF PART</b>	<b>NO. REQ.</b>
1	06-81-1700	M5 x 0.8 x 5. lg, 3mm Skt. Hd. Sld. Sc.	2
★ 2	43-56-0315	Gliding Assembly (Incl. 3,4,5)	1
3	42-40-0001	Distance Bearing Bushing	1
★ 4	06-95-1000	M3.5 x 22. lg, Phillips Pan Hd. Plast. Sc.	1
★ 5	06-95-1005	M3.5 x 24. lg, Phillips Pan Hd. Plast. Sc.	3
6	40-50-0405	Spring (Blue)	1
7	43-76-0050	Housing	1
8	44-66-1500	Mounting Plate	1
9	06-81-2000	M4 x 0.7 x 8. lg, 2.5mm Skt. Hd. Flat Sc.	3
10	44-66-0305	Curve Plate	1
11	06-81-2005	M4 x 0.7 x 10. lg, 2.5mm Skt. Hd. Flat Sc.	1
12	43-72-0010	Bit Holder	1
13	43-56-0300	Spring Guide	1
★ 14	43-76-0296	Adapter Assembly	1
16	34-40-0700	O-Ring	2
17	44-40-0575	Stop Nut	2
18	48-30-1521	120mm #2 Phillips Bit (Not Shown)	1
18A	48-30-1526	120mm #2 Square Bit	1
19	06-81-2010	M5 x 0.8 x 25. lg, 4mm Skt. Hd. Sld. Sc.	1
20	43-62-1230	Handle	1
21	06-81-2015	M5 x 0.8 x 25. lg, 3mm Skt. Hd. Sld. Sc.	1
22	43-56-0305	Plastic Belt Guide (Incl. 23,24,25)	1
23	43-56-0320	Belt Guide-Right	1
24	43-56-0325	Belt Guide-Left	1
25	06-95-1010	Assembly Guide Screw	2
26	06-81-2020	M5 x 0.8 x 12 lg, 4mm Skt.1 Hd. Pan Sc.	1
27	06-81-2025	M5 x 0.8, 3mm Socket Hd. Roller Screw	1

<b>FIG.</b>	<b>PART NO.</b>	<b>DESCRIPTION OF PART</b>	<b>NO. REQ.</b>
28	44-60-1520	Pivot Pin	1
29	42-74-0095	Gear Wheel Unit	1
★ 30	43-46-0207	Depth Control, 1" to 2-1/4"	1
	49-96-4800	Hex Key Set-2, 2.5, 3 & 4mm (Not Shown)	1
	10-15-6100	Depth Label (Not Shown)	1
	12-25-1470	Warning Label (Not Shown)	1


**FIG. NOTES:**

9,11 Use Loctite 272 on screws.

**SEE REVERSE SIDE FOR 20.5" EXTENSION PARTS**

**MILWAUKEE ELECTRIC TOOL CORPORATION**  
13135 W. LISBON RD., BROOKFIELD, WI 53005  
Dwg. 2

## **20.5" EXTENSION PARTS**



**★=Part number change from previous service parts list**

<b>FIG.</b>	<b>PART NO.</b>	<b>DESCRIPTION OF PART</b>	<b>NO. REQ.</b>
17	44-40-0575	Stop Nut	2
★ 34	14-38-0677	Extension Tube & Shaft Subassembly (Incl. 17,35,38,50,51)	1
★ 35	45-76-0307	Extension Tube	1
38	45-08-0026	Extension Drive Shaft	1
39	14-38-0685	Screw Guide Subassembly (Incl. 40,41,42,43,44)	1
40	-----	Screw Guide	1
41	06-81-2035	M5 x 0.8 x 10. lg, 3mm Socket Hd. Screw	1
42	43-56-0330	Slotted Guide Screw	1
43	06-81-2040	M4 x 0.7 x 25. lg, 3mm Socket Hd. Screw	2
44	-----	Clamp	1
★ 46	14-34-0506	Side Handle Subassembly	1
50	34-40-0700	30 x 25 x 2.5mm O-Ring	2
51	06-83-1400	M6 x 1.0 x 6 lg, 3mm Socket Hd. Set Screw	2