



SERVICE PARTS LIST

BULLETIN NO.
54-49-0285

SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS		REVISED BULLETIN	DATE
72" HIGH CAPACITY MOBILE WORK BENCH			Aug 2024
CATALOG NO.	48-22-8572	SERIAL NO.	L29A
		WIRING INSTRUCTION	

00
0

EXAMPLE:
Component Parts (Small #) Are Included When Ordering The Assembly (Large #).

NOTE: See page 2 for drawer slide removal and installation.





FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
1	14-46-1633	Cord Grommet (Set of 1)	(2)
2	14-46-1645	Cord Storage Bracket Kit	(2)
3		Cord Storage Bracket	(2)
4		M4 x 12mm Screw	(4)
5	14-46-1632	Side Handle Kit	(2)
5a		Side Handle	(1)
5b		M6 x 16mm Bolt	(4)
6	14-46-1343	4-outlet Power Strip (inside Drawer)	(1)
7	14-46-1342	6-outlet Power Strip w/ Faceplate Kit	(1)
7a		6-outlet Power Strip	(1)
7b		Faceplate	(1)
7c		M4 x 12mm Bolt	(6)
8	14-46-1662	Drawer Slide Kit (Set of 2)	(1)
8a		Inner Drawer Slide	(2)
8b		Outer Drawer Slide	(2)
8c		5/32" Pop Rivet	(14)
9	42-38-0272	Corner Bumper/Extrusion Kit (Set of 2)	(1)
9a		Corner Guard	(2)
9b		Front Corner Bumper	(4)
9c		Rear Corner Bumper	(2)
9d		M4 x 16mm Bolt	(12)
10	14-46-1637	Swivel Caster Kit (Set of 2)	(2)
10a		Swivel Caster w/ Brake	(4)
11	14-46-1634	Rigid Caster Kit (Set of 2)	(1)
11a		Rigid Caster	(2)
11b		M8 x 18mm Bolt	(16)
11c		Washer	(16)
11d		Spanner Wrench	(2)
12	14-46-1636	Key/Lock Kit	(2)
13	14-46-1651	Side Tray Kit	(1)

FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
13a		Side Tray	(1)
13b		Side Tray Holder	(2)
13c		M6 x 8.5mm Round Head Bolt	(2)
13d		Nylon Washer	(2)
13e		M6 Blk Nut	(2)
13f		EVA Sticker	(2)
13g		M6 x 16mm Hex Bolt	(4)
14	58-95-8572	Drawer Liner Kit (Set of 18, Not Shown)	(1)
15	12-20-0109	Service Nameplate (Not Shown)	(1)
16	14-46-1639	Plastic Conduit Chain Kit	(1)
16a		Plastic Conduit Chain	(1)
16b		M6 x 12mm Bolt (Not shown)	(6)
17	10-22-1759	Electrical Label	(1)
18	14-46-1638	Tool Organizer	(1)
19	48-22-8599	Bottle Opener Kit	(1)
19a		Bottle Opener	(1)
19b		M6 x 16mm Bolt (Not shown)	(2)
19c		M6 x 20mm Screw	(2)
20	31-01-8559	Steel Storage Logo Badge	(1)

FIG. NOTES
15,17 A clean, dry surface is essential for proper performance for any adhesive system. The area intended for application of any adhesive label or nameplate must be prepared by cleaning with isopropyl alcohol. The solvent is to be applied with a clean, lint free applicator and the surface allowed to dry before applying the label or nameplate.


MILWAUKEE TOOL • www.milwaukeetool.com
13135 W. LISBON RD., BROOKFIELD, WI 53005
Drwg. 1

Cat. No. 48-22-8520 shown




Inner Slide

To remove drawer slide, remove rivets (15) from the inner slide (13) and outer slide (14) by 5/32" drill bit.




Outer Slide

To install drawer slide, place inner slide (13) into position and insert rivets (15) by using a rivet gun. Repeat steps for outer slide (14).



Inner Slide



Outer Slide