



SERVICE PARTS LIST

BULLETIN NO.
54-49-8545

SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS		REVISED BULLETIN	DATE
40" MOBILE WORK STATION			Feb. 2019
WOOD CATALOG NO. 48-22-8544A	SERIAL NUMBER K78A	WIRING INSTRUCTION	


00 0

EXAMPLE:
Component Parts (Small #) Are Included
When Ordering The Assembly (Large #).

14-46-1657

Hardware Kit

3	-----	Bolt M6 x 16L	(4)
8	-----	Screw M4 x 12L	(4)
10	-----	Screw M4 x 16L	(4)
13	-----	Bolt M6 x 16L	(4)
16	-----	Nut M6	(2)
17	-----	Washer	(2)
18	-----	Bolt M6 x 8.5L	(2)
27	-----	Washer 19 x 8.5 x 2	(16)
28	-----	Bolt M8 x 18L	(16)
34	-----	Screw M4 x 16L	(8)
39	-----	Screw M6 x 16L	(2)
--	-----	Charger Mounting Screw M4 x 12L	(4)



NOTE: See page 2
for drawer slide removal
and installation.


FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.	FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
1	22-90-0105	Cord Grommet	(1)	28	-----	Bolt M8 x 18L	(16)
2	14-46-1663	Side Handle Kit	(1)	29	14-46-1643	Key/Lock Kit	(1)
3	-----	Bolt M6 x 16L	(4)	30	-----	Key	(1)
4	-----	Side Handle	(1)	31	-----	Lock	(1)
5	14-46-1641	Power Strip	(1)	32	42-38-0268	Corner Bumper/Extrusion Kit (Set of 2)	(1)
6	14-46-1645	Cord Storage Bracket Kit	(1)	33	-----	Corner Guard	(2)
7	-----	Cord Storage Bracket	(2)	34	-----	Screw M4 x 16L	(8)
8	-----	Screw M4 x 12L	(4)	35	-----	Corner Bumper	(4)
9	42-38-0269	Rear Bumper Kit	(1)	36	48-22-8599	Bottle Opener Kit	(1)
10	-----	Screw M4 x 16L	(4)	37	-----	Bottle Opener	(1)
11	-----	Rear Bumper	(2)	38	-----	Screw M6 x 20L	(2)
12	14-46-1664	Storage Shelf Kit	(1)	39	-----	Screw M6 x 16L	(2)
13	-----	Bolt M6 x 16L	(4)	40	45-64-0020	Stainless Steel Top	(1)
14	-----	Storage Shelf	(1)	41	58-95-0182	Drawer Liner Kit (Set of 6)(Not Shown)	(1)
15	-----	Storage Shelf Bracket	(2)	42	12-20-0109	Service Nameplate (Not Shown)	(1)
16	-----	Nut M6	(2)	43	12-25-1814	Electrical Label (Not Shown)	(1)
17	-----	Washer	(2)				
18	-----	Bolt M6 x 8.5L	(2)				
19	14-46-1245	Caster Kit (Set of 4)	(1)				
20	-----	Swivel Caster with Brake	(2)				
21	14-46-1285	Drawer Slide Kit (Set of 2)	(1)				
22	-----	Outer Drawer Slide	(2)				
23	-----	5/32" Pop Rivet	(12)				
24	-----	Inner Drawer Slide	(2)				
25	31-21-0107	Center Divider	(1)				
26	-----	Rigid Caster	(2)				
27	-----	Washer 19 x 8.5 x 2	(16)				

FIG. NOTES

42,43 A clean, dry surface is essential for proper performance for any adhesive system. The area intended for application of any adhesive label or nameplate must be prepared by cleaning with isopropyl alcohol. The solvent is to be applied with a clean, lint free applicator and the surface allowed to dry before applying the label or nameplate.


MILWAUKEE TOOL • www.milwaukeetool.com
13135 W. LISBON RD., BROOKFIELD, WI 53005
Drwg. 1

Cat. No. 48-22-8520 shown




Inner Slide

To remove drawer slide, remove rivets (23) from the inner slide (24) and outer slide (22) by 5/32" drill bit.




Outer Slide

To install drawer slide, place inner slide (24) into position and insert rivets (23) by using a rivet gun. Repeat steps for outer slide (22).



Inner Slide



Outer Slide